

Video Projection of iBook Computer Image using AV Cable

AV Cable Connection

Connect AV cable's mini plug to the jack on left side of an iBook.

Connect the AV cable's yellow plug to the video input of a classroom VCR.

Optional if sound is required: Plug the AV cable's red or white or both plugs to the audio input of a classroom VCR.

VCR Settings

Turn on the VCR.

Turn to Channel AU or F-1

Press the Menu button twice.

Monitor (TV) Settings

Turn on the monitor.

Set to channel 3.

Turn on the computer.