

Sanyo Video Projector Directions

TO START

1. With all equipment off connect projector power cable to wall outlet and the cable between projector and computer.
2. Press video projector's ON-OFF button; then start computer.
3. The projector counts down from 30 before it projects an image.
4. On video projector, press MODE to toggle to COMPUTER image setting.
5. Depending on the model, turn FOCUS ring on lens or press FOCUS button to adjust image focus.
6. Depending on the model, turn ZOOM ring (with knob) on lens or press ZOOM button to make the image larger or smaller.
7. Release foot latches on both sides to raise/lower feet and then lock; fine tune by rotating the feet.

TO TURN OFF

1. Press video projector's ON-OFF button twice.
(IMPORTANT -- Fan will continue running for 1 minute. DO NOT disconnect power until fan has stopped. This will greatly increase the life of the projector lamp.)
2. Shut down computer.
3. If projector fan has stopped, unplug cables.
4. **IMPORTANT** – Put cap back on the lens.